

# **KEY FEATURES**

- \* Designed to match the natural shape of your spine.
- \* Herma buckle to make it easier to use any buckle anywhere.
- \* Large, removable lid that can be adjusted in height and used as a separate backpack.
- \* Large top of lid compartment with zip.
- \* Front of lid compartment with zip.
- \* Two ports in the top for antenna, cables or hydration access.
- \* Padded shoulder pads with chest strap.
- \* Large inverse U-shaped opening on the front.
- \* Large inverse U-shaped opening in the bottom for the sleeping bag compartment.
- \* Two large side pockets that are attached with zippers.
- \* The hip belt is centre attached, making it free to move with your body

## **VERSIONS**

\* 29-01161C09-100, 100L Backpack 2.0, Grey

#### **MATERIALS**

- \* 100% Nylon -PU coated
- \* All fabrics, buckles and webbing's are IRR compliant.
- \* Outside/main fabric is FR.

## **DIMENSIONS**

100L

H=, W=, D=

#### WEIGHT

4,1 kg

## PARTS IN THE BACKPACK



One backpack



One waist belt



One lid



One plastic sheet frame with aluminium stays



One pair of zipped side pockets





Helmet holder with elastic string, holds all types of helmets. A wet jacket/poncho or similar can also be stored here.

The top compartment on the lid is big and has zipped opening on both the front and the back.

Zipped 3L front compartment on the lid which is easy to access and use. It has a big Velcro patch on the front for patches.

The lid is large and completely covers the backpack top. It can easily be removed and used as a mission backpack.

The main compartment has a large U-shaped zipped opening to access the top part of the backpack.

Two 11L side pockets with zip openings on both sides to give easy access in all positions. Stores your rain gear, insulated jacket, ghillie jacket and personal kitchen as well as 24 hours food.

The sleeping bag compartment in the bottom of the backpack can also be accessed through a U-shaped opening in the bottom of the backpack

Straps with side release buckles makes it possible to attach a tent, mattress or similar on the bottom of the backpack.

All zippers have large toggles to be easy to grab, even with gloves.

All straps have Velcro roll up ends to secure them.



- Rigid head hole and cut out in the lid so you can bend your head back when wearing the backpack.
- Long zipper for good access to the top compartment on the lid. The lid height can be adjusted, depending on how much you have in the main pack.
- Handle.
- Top tension straps to adjust how tight the backpack sits.
- Opening for antennae, cables or a hydration tube.
- Shoulder straps with plastic sheet and firm foam with holes for ventilation. This is the optimal solution with the plastic sheet distributing the pressure over the foam.
- Holder for team radio microphone.
  - 10 mm webbing loops along the side where you can attach the duffel straps.
- Chest strap.
- Ventilated back cushion.
- Six outside attachment points for a duffel strap on the side pockets.
- Hip belt with plastic sheet and firm foam with holes for ventilation.
  - The hip belt is centre attached, making it free to move with your body
- Side tension strap
- Sledge attachment ring

The inside of the backpack has a light colour to make it easier to find what you are looking for inside the backpack.



The hip belt moves with your body. The picture shows how it looks when you take a step with your left foot

This feature saves energy and lets your legs move freely.



The picture shows how it looks when you take a step with your right foot.

This function saves energy.



One large opening on the front of the main compartment and one for the sleeping bag compartment makes it easy to access the backpack even when it is fully packed.



The hip belt is shaped to fit around your hips.

It has a stiff outer layer to take the weight from the backpack and a soft inner layer to be comfortable to use.



The frame is strong and shaped to match the curve of your back.



The back is shaped after your back to sit comfortably and to make it easier to carry body armour.

The backpack is thin to keep the centre of gravity close to your body= Easier to carry.



The side pockets are attached with zippers and can be removed and carried together or individually as a backpack.

The pockets can be opened in either side to always be easy to reach.



The backpack lid has two inside zipped compartments.



The lid has two outside compartments with zipped opening.